



MOTOROKR™ EQ5

Quick Start Guide



Figure 1




Figure 2



Figure 3



Figure 4



European Union Directives Conformance Statement



Hereby, Motorola Inc., declares that this MOTOROKR™ EQ5 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (the R&TTE Directive) at www.motorola.com/rtte.

Caring for the Environment by Recycling



When you see this symbol on a Motorola product, do not dispose the product with household waste.

Recycling Mobile Phones and Accessories

Do not dispose of mobile phones or electrical accessories, such as chargers or headsets, with your household waste. In some countries or regions, collection systems are set up to handle electrical and electronic waste items. Contact your regional authorities for more details. If collection systems aren't available, return unwanted mobile phones or electrical accessories to any Motorola Approved Service Centre in your region.

FCC Notice to Users

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. See-47-CFR-Sec.-15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See-47-CFR-Sec.-15.19(3).

Welcome

The **MOTOROKR™** EQ5 Ultra-Portable Wireless Speaker is sleek, stylish and pocket-sized. It's the perfect companion to your MP3 player or music phone.

- **Pocket portability**—The sleek, slim design fits comfortably in your pocket, so your music and speakerphone calls can go anywhere you go.
- **Expand your sound**—The EQ5 delivers high-definition stereo sound powered by SRS™ WOW HD™ enhanced audio technology.
- **Don't miss a call**—When paired with your phone, the **MOTOROKR™** EQ5 doubles as a speakerphone with echo-cancellation and noise-reduction to keep you sounding clear. Switch between music and calls with the touch of a button.
- **Wireless mobility**—Tangled wires are a thing of the past. Bluetooth stereo connectivity cuts the speaker cable, and the rechargeable battery unplugs you from the wall. Integrated music and call controls mean there's no need to reach for your phone, and your music automatically pauses with each call.

Before you begin

See figure 1 on page 1

Take a moment before you get started to familiarize yourself with the components of your speaker.

1. Volume Buttons
2. Call Button
3. Microphone (on side)
4. Audio In Port (on side behind flap)
5. Forward Button
6. Power Switch (on bottom)
7. Play/Pause Button
8. Reverse Button
9. Charging Port and Light (behind flap)
10. Main Indicator Light

Charge your speaker

See figure 2 on page 2

You'll need to charge your speaker's battery for a minimum of 1 hour using the included charger.

Note: The speaker is operational while charging.

The Charging indicator light turns red when battery is charging. It may take up to 1 minute for the indicator light to turn on. When the speaker's battery is fully charged, the indicator light turns green.

To check your speaker's battery charge level, press and hold both Volume buttons. The main indicator light displays charge status until the Volume buttons are released.

Main Indicator Light	Battery Charge Status
Red	Less than 30% charge
Yellow	Between 30% and 70% charge
Green	More than 70% charge

When your speaker is in a low battery charge state, the main indicator light flashes quickly in red, and a tone is repeated every minute.

Turn it on & off

See figure 3 on page 2

To turn your speaker on and off, slide the Power switch to the ON position. The main indicator light flashes 3 times.

Connect your speaker

Connect wirelessly

To listen to your music via Bluetooth wireless connection, as well as make and receive handsfree calls, you need to pair (link) your speaker with your Bluetooth phone and/or music player.

1. Turn off any Bluetooth devices previously paired with your speaker.
2. Turn on the Bluetooth feature on your Bluetooth phone or music player.
3. Turn on your speaker.
The main indicator light is steadily lit in blue to indicate the speaker is in discoverable mode.
4. Place phone or music player in Bluetooth search mode.
The phone or music player searches for your speaker.
5. Select **Motorola EQ5** from search results on your phone or music player and confirm pairing following the on-screen instructions.
6. If prompted, enter **0000** passkey.

When your speaker successfully pairs and connects with your phone or music player, the main indicator light flashes blue and purple. Music playing from your connected music source is heard on your speaker.

After successfully pairing your speaker and Bluetooth device, you don't need to repeat these steps. For each use, ensure that your speaker is turned ON and that your device's Bluetooth feature is ON.

Some music devices will automatically attempt to play music when the EQ5 re-connects to it.

Connect wirelessly to 2 devices (multipoint connection)

To connect to phone and music device at the same time:

1. Pair and connect to your phone first (see section “Connect Wirelessly”).
2. Turn off your phone and your speaker.
3. Turn your speaker back on. The Bluetooth indicator flashes to indicate the speaker is in discoverable mode.
4. Turn on your music device. Make sure the Bluetooth feature is turned on in the device.
The music device searches for your speaker.
5. Complete steps 5 & 6 on section “Connect Wirelessly” to pair and connect your music device and speaker successfully.
6. Turn off your speaker.
7. Turn your phone back on and make sure the Bluetooth feature is turned on in both the phone and music device.
8. Turn your speaker system back on. It should now connect to both devices.

Connect with a cable

To listen to your music using a wired connection, connect your music player to the Audio port on your speaker using the included audio cable.

See figure 4 on page 2

Notes:

- *The Audio port functions as an input port from a music device only (not as a headphone jack).*
- *Playback controls provided on your speaker cannot be used when listening to music input from wired connection.*
- *In wired connection, if no audio is heard turn up volume on music device.*

Control your tunes

See figure 1 on page 1

Playback controls on your speaker can be used when listening to wireless music streaming from a Bluetooth-enabled music player that also provides remote control capabilities (AVRCP).

When remote control capabilities are not supported by your music player, the EQ5 simply acts as a speaker, and music should be controlled from your music player.

	Short press —play/pause music Long press —stop music
	Short press —skip to previous track Long press —rewind track*
	Short press —skip to next track Long press —fast-forward track*
 or 	Short or long press —decrease or increase volume**

* If your music player supports this feature

** You'll hear a tone when maximum or minimum volume is reached on your speaker.

The volume setting on your music player may impact volume on your speaker.

Make and receive handsfree calls

To make and receive calls using the speaker, a Bluetooth handsfree (HFP) connection must be established with your phone

Make a call

Using the speaker to make a call, you can redial the last dialed number or make a voice dial call (if your phone supports this feature). When making a voice dial call, the microphone on the speaker is enabled, and you hear a prompt from your phone.



Short press—make a voice dial call (you hear a prompt from your phone)

Long press—redial last number

Receive a call

When there's an incoming call, the main indicator light flashes quickly in blue on your speaker, and you hear a ring tone over your speaker. If music is playing when a call is received, the music pauses or mutes, depending on your music player and connection setup.



Short press—answer call



Long press on either button—reject call

While on a call

When a call is active, the main indicator light slowly pulses in blue on your speaker.



Short or long press—adjust call volume



Short press—mute call (main indicator light pulses in purple while muted)



Short press—end call

When there's a second incoming call, the main indicator light flashes quickly in blue on your speaker and you hear an alert.



Short press—

1. answer second call (first call is placed on hold),
2. end second call (first call resumes),
3. resume first call on hold (when second caller hangs up)



Long press (either button)—reject second incoming call*

* If your phone supports this feature.

Indicator light

The main indicator light on your speaker displays current status of Bluetooth wireless connection(s) to your phone and/or music player.

Main Indicator Light	Wireless Status
Steady blue	Pairing mode
Long blue flash	Standby (handsfree connection only)
Long yellow flash	Standby (streaming music connection only)
Long green flash	Standby (both handsfree and streaming music connection)
Quick blue flash	Incoming/outgoing call
Long blue pulse	Connected on a call
Long purple pulse	Connected call muted
3 green flashes	Started/paused music player
Long green pulse	Music streaming (with handsfree connection active)
Long yellow pulse	Music streaming (without handsfree connection active)
Long purple pulse	Music from wired connection active
2 yellow flashes	SRS WOW HD on/off
3 yellow flashes	Stopped music player
Slow red flash	Idle (not connected to a device)

Additional tips

Pairing

- **To initiate pairing (discoverable) mode manually** when your speaker is already powered on, press and hold both **Call** and **Play/Pause** buttons at the same time.
- **To clear paired devices list in your speaker**, press and hold both **Reverse** and **Forward** buttons at the same time until speaker resets.

Disabling SRS WOW HD

SRS WOW HD is an audio enhancement technology that provides better width and improved bass and definition control. This feature is enabled on your speaker at purchase.

If your music player also has SRS or any other sound enhancement technology, best audio results may be achieved if the audio enhancement feature is enabled on only either the music source or the speaker (but not both).

To disable the SRS WOW HD audio enhancement feature on your speaker, press and hold the **Play/Pause** and **Rewind** buttons at the same time until you hear a tone and the main indicator light flashes yellow twice. To re-enable the SRS feature, perform the same action.

If you have any additional questions, please call your hotline number (0870-9010-555) or visit us at www.hellomoto.com.

motorola.com

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Motorola, Inc. is under license. © 2007 Motorola, Inc. All rights reserved.

6803578F36